


A leader doesn't follow steps
... he marks the way



WHAT'S AN ECO DIVIDER?

A lane divider. Its main function is to reduce the motorist's speed since they have to center the car to cross over the Eco divider.

It's mostly recommended in **schools, pedestrian crossings, hospitals, and places where it's necessary to reduce the speed.**


Features

- A device that serves to center or direct vehicle traffic on big avenues.
- It's complemented by a reflective that works with the headlights of vehicles.
- Anti-skid to avoid accidents.
- Made of medium-density polyethylene, a material that doesn't damage vehicles. It's just one solid piece.
- Colors: Black or yellow. Maintenance-free.
- Weather-resistant and UV rays protected.
- Highly resistant to vehicle impacts. They're almost unbreakable.
- The Eco divider has the option of adding a Poliflexy® 66 Bollard to improve the visibility from afar since it has 2 reflective stripes.
- It also has the option of adding a solar LED stud. This warns drivers from afar.

• It's installed with 3 anchors (not included).

STUD CHARACTERISTICS


- A stud with a smart solar power system.
- Solar panel and high-efficiency electric system.
- Translucent amber LEDs with an operational angle of 30 degrees.
- Flash frequency of 3 Hz.
- An exclusive system for dissuasive humps.
- It isn't designed for individual use. The optical design of the acrylic micas only shows its efficiency when they're placed on speed bumps.



ECO DIVIDER

Code: ECO-DIV -28

Volumes, dimensions, and other measures are nominal and may vary by approximately 2 %.



Measures

Total	Length: 47 in.
	Width: 10.92 in.
	Height: 4.68 in.
	Height with bollard: 29.05 in.
Reflective:	Solar stud
LED color:	Blue and amber.
Approx. weight:	36.8 lb.

Make sure to center the Eco divider to the street or avenue. The correct position is with the stud looking towards the driver.

The Eco divider will act as a template. Mark the holes with a drill and a ½" drill bit. Then, bore into the marked area at a depth of 3". Put the Eco divider and insert the anchors. Hammer away with the help of a 6 lb. mallet.

